

Tru-Lite Shed Light Installation Instructions



LOCATE A POSITION INSIDE THE SHED ROOF WHERE YOU WANT THE SHED LIGHT LOCATED.

MARK THE CENTER BETWEEN THE ROOF JOISTS 10 INCHES DOWN FROM THE PEAK. DRIVE A NAIL UP THROUGH THE ROOF AT YOUR MARK TO HELP IN POSITIONING THE ROOF JACK.



PLACE THE JACK OVER THE NAIL, CENTERING THE OPENING.



DRAW A CIRCLE USING THE ROOF JACK OPENING AS A TEMPLATE.



CUT OUT THE CIRCLE DRAWN IN THE PREVIOUS STEP

SAND THE SIDES OF THE CUT OUT HOLE TO REMOVE ROUGH AREAS

Tru-Lite Skylights 800-873-3309



LAY MASTIC ON THE BOTTOM SIDE OF THE ROOF JACK (SIDES FIRST, THEN TOP AND BOTTOM)



POSITION THE ROOF JACK OVER THE HOLE.

USE THE SUPPLIED SELF SEALING SCREWS TO ATTACH THE ROOF JACK TO THE ROOF



CAREFULLY DROP IN THE PRISMATIC DIFFUSER INTO THE TOP OF THE ROOF JACK (PRISMS DOWN)



ATTACH THE DOME TO THE ROOF JACK USING THE SUPPLIED SCREWS

ENJOY THE LIGHT !!